



TAUNOTENT

INSTRUCTIONS FOR FITMENT



These fitment instructions apply to:
FIAT Fullback: Single Cab

Clip on with and without
sports-bar

Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

TOOLS:

Only tools required are a drill and 10mm drill bit, rivet nut tool and a number 10 spanner.

KIT COMPRISES:

- 1x Tonneau cover
- 3x Support braces
- 6x Support clips
- 1x Front rail
- 3x Rivnuts with 3x bolts and nuts.
- 2x Side rails, with plastic plugs
- 1x Back rail
- 2x back corners with 4x screws
- 6x G clamps and high levelling screws

1) Fit front rail as per photo.




2) Make holes according to rail and drill using 10mm drill bit. Insert rivnuts into holes and use screws, to attach rail to edge.



3) Fasten the two side rails using 3x clamps per rail. The plastic caps must sit flush with the front outside edge of the aluminum rail which just has been attached. See Picture. **Please note how the front rail has been fitted.**



4) Install the rear rail over the tail gate by pushing the ends of the corners into the open ends of the side rails. Fasten into place by turning* hand screws as tightly as Possible.



5) Insert support braces into bow clips according to labels front and back. Slide cover into front rail and close velcro around sports-bar (if have) and then pull cover towards tailgate.




TAUNOTENT

INSTRUCTIONS FOR FITMENT CONTINUED

Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

6) Line up all the chips at tailgate first and then push them all down at once so that they clip into the rail. Do the same on the two sides. When removing the cover start by lifting up the corners to loosen the chips



7) The tailgate can open and close with the cover fitted.

8) The cover can be rolled to the front and fastened using the straps.

9) Should any part of the kit be lost or broken they can be purchased separately .



Retighten clamps and hand screws regularly as they tend to open while travelling

Should you experience any problems in fitting please do not hesitate to call us on 011 026 4790

Warranty: The stitching is guaranteed for 6 months. Please only use Sunlight dish soap to wash the cover and Dubbin to polish. All car wash products and polishes should not be used on the tonneau cover, as well as, high pressure hoses and brushes.



TAUNOTENT

+27 (0) 11 026 4790 / (0) 11 455 0627

www.taunotent.co.za info@taunotent.co.za

Unit 3, 159 Greenwale Road, Wilbart, Germiston