



TAUNOTENT

INSTRUCTIONS FOR FITMENT



This fitment instruction apply to:
**ISUZU 2013: Double Cab and
Extended Cab**

Clip on
Tonneau kit
with sportbar.

ISUZU DOUBLE CAB WITH
ARTAV NEW SPORTBAR.

1. Secure the front aluminum slide rail to the Load body (as per picture). If there is rubberizing blocking the bolt holes, use the rail to locate the position and clean out the rubber. The shorter lip of the rail to be positioned towards the tailgate. Align the holes in the rail with the holes on the edge and secure rail with 3x bolts supplied in packet.



2. Fasten the two side rails using 2x clamps per rail (front and back).



3. Install the rear rail over the tail gate by pushing the ends of the plastic corners into the side rails. Fasten into place by turning grip screw as tightly as possible, so that the rail may only be pulled out once the screws have been loosened.



4. Insert support braces into bow clips ensuring they are equally spaced along the length of the load box. Slide cover into front rail. Close Velcro around roll-bar and then pull cover to the tailgate.





TAUNOTENT

INSTRUCTIONS FOR FITMENT CONTINUED

5. Starting from the tailgate make sure the cover is centered then line up all the chips and then push them all down so that they clip into the rail.



6. Doing the same as you did at the tail gate clip the sides of the cover into the two side rails.



Retighten clamps and hand screws regularly as they tend to open while travelling. Should you experience any problems in fitting please do not hesitate to call us on 011 026 4790

