



TAUNOTENT

# FITMENT INSTRUCTIONS

 <b>TONNEAU COVER</b>	<p>This fitment instruction apply to: <b>NISSAN NP200</b></p>	<p>Clip on Tonneau kit with and without roll bar</p>	<p>NISSAN NP200</p>
--	---	--	---------------------

### CONTENTS:

- |                                  |                            |                                    |                            |
|----------------------------------|----------------------------|------------------------------------|----------------------------|
| 1) 1 x front aluminum slide rail | 4) 6 x rivnuts             | 8) 2 x support braces              | 12) 2 x bolts with washers |
| 2) 2 x side rails                | 5) 4 x bow-clips           | 9) 2 x back corners                | 13) 1 x tonneau cover      |
| 3) 1 x back rail                 | 6) 2 x plastic end caps    | 10) 4 x back corner screws         | 14) 12 x pop-rivets        |
|                                  | 7) 6 x screws with washers | 11) 6 x side rail support brackets |                            |

### INSTRUCTIONS FOR FITMENT

1) Remove all plastic handles around the load box of the vehicle. You will also need to remove all screws on the inside of the load-box securing the plastic liner to the vehicle (as seen on pictures on right).



2) Once all screws have been removed you can now remove the plastic liner on each side of the vehicle (as seen in last picture on right).



3) Once you have removed the plastic liner you will see there are 6 plastic plug thread inserts, remove the 3 as indicated by the red arrows in picture on right. Once removed you will notice the holes are square in shape. Take a 10mm drill bit and expand the holes. After expanding the holes secure the rivnuts provided. Do the same on both sides, once completed you can now re-secure the plastic liners on both side including the handles you removed in step 1.





TAUNOTENT

# FITMENT INSTRUCTIONS

*Fitment instructions continued*

 <p>TONNEAU COVER</p>	<p>These fitment instructions apply to: NISSAN NP200</p>	<p>Clip on Tonneau kit with and without roll bar</p>	<p>NISSAN NP200</p>
---	--	--	---------------------

5. Once you have re-secured the plastic liner place the aluminum side rails on the vehicle. You can now start securing the side rail support brackets, these will be secured in the rivnuts you secured in the previous steps. **NB Before securing this bracket you need to ensure that the back rail sits flush on the tailgate of the vehicle and there is no gap present between the middle of the tail gate of the vehicle and middle of the aluminium back rail. Please take note of how the back rail is sitting in picture on right.**



6. Once you are happy with the way the back rail is sitting, secure the side rail mounting brackets by drilling into the holes of the bracket and into the side rails. Secure using the pop-rivets provided. Secure all 6 side rail support brackets.



7. Remove the 2 plastic screws caps located in the front of the load box of the vehicle. Before securing the front rail to the front of the vehicle slide the cover into the front mounting bracket and then secure to the front of the vehicle with the 2 x bolts provided.



8. Finally insert the support braces provided (The support to be placed closer to the cab of the vehicle is longer than the one closer to the tailgate of the vehicle). Pull the cover to the back of the vehicle and clip the chips into the frame, starting from the back and finishing on the sides.



Should you experience any problems in fitting please do not hesitate to call us on 0861 82 8668