



TAUNOTENT

## FITMENT INSTRUCTIONS



TONNEAU  
COVER

*This fitment applies to a Nissan NP200 tie  
on tonneau kit with and without roll bar  
2004-2011 tie on tonneau kit*

*Nissan NP200  
With and without roll bar*

Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

### TOOLS:

Electric Drill, 4.5mm & 5mm steel drill bit & 8mm drill piece for the self-tapping drill screws, extension cord, pop-rivet gun, tape measure, pencil, all appropriate safety equipment and all parts provided in the tonneau kit.

Note: After any holes are drilled apply rust inhibitor (provided) before any screws or rivets are fastened

### INSTRUCTIONS FOR FITMENT

1. Before commencing fitment, check the contents of the kit and ensure it is the correct cover for your bakkie by laying it over the load-body and ensuring it fits correctly.
2. Aluminium rail fits under the window open end facing up leaving an even gap on either side. Secure the rail by removing the existing bolts in the front of the load box just under the rear window then place aluminium rail so the holes line up now re-secure the bolts. To secure the centre of the rail use 2x self-taping drill screws with an 8mm drill piece. Space the self-taping drill screws evenly apart from the centre and the end of the existing bolts securing the rail.
3. Pull cover towards back. You will see one strip sewn across the cover. The support brace goes across the load box in the centre of this strip. Mark centre points and fit bow clips flush with top edge of load box using a 5mm drill bit and 4 x of the long rivets with the extended centre.
4. Pull cover to back over tail gate. Turn up hem and mark centres of the eyelets along tailgate and the sides of the vehicle (just below the plastic liner of the vehicle) and one on either back corner between loops, stitched on underside. Drill using a 4.5mm drill bit and pop rivet bobbins. Please note when rivetting the bobbins on the back corners the slightly longer and thicker poprivets must be used.
5. At the front fit one saddle hook on either side behind door to tie off ends of shock cord.
6. Once fitted the cover should fit tight and secure. Check that the elastic is pulled tight and that the support brace is inserted and working correctly.

Only use a mild soap when cleaning your cover.

Thank you for your purchase, we hope it meets your requirements adequately

**Should you experience any problems in fitting please do not hesitate to call us on 0861 82 8668**