



TAUNOTENT

INSTRUCTIONS FOR FITMENT



TONNEAU
COVER

*This fitment applies to an Isuzu with cab
protector 2004 onwards.*

*Part NO:
TT42*

Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

TOOLS:

Electric Drill, 4.5mm steel drill bit, extension cord, pop-rivet gun, tape measure, pencil, all appropriate safety equipment, and all parts provided in the tonneau kit.

Note: After any holes are drilled apply rust inhibitor (provided) before any screws or rivets are fastened

1. Before commencing fitment, check the contents of the kit and ensure it is the correct cover for your bakkie by laying it over the load-body and ensuring it fits correctly.
2. Climb into load box and have one person on either side to pull the cover evenly across. Mark centre turn buttons and fit these first then move outwards pulling the cover to avoid bulging and fit one by one. Cover to be flush with outside front edge of load box.
3. Clip cover on turn buttons and pull towards the tailgate. You will see two strips sewn across the cover. The support braces go across the load box in the centre of these strips. Mark centre points and fit bow clips flush with top edge of load box using self-taping drill screws.
4. Insert longer support brace towards window and shorter towards tail gate.
5. Pull cover to back over tail gate. Turn up hem and mark centres of the back corners between loops, stitched on underside. Drill and pop rivet one bobbin on each corner.
6. At the front fit one saddle hook on either side as close to the front edge of the load box on to which the ends of the shock cord will be tied.
7. Once fitted the cover should fit tight and secure. Check that the elastic is pulled tight and that the support brace is inserted and working correctly.

Only use a mild soap when cleaning your cover.

Thank you for your purchase, we hope it meets your requirements adequately.

Warranty: The stitching is guaranteed for 6 months. Please only use Sunlight dish soap to wash the cover and Dubbin to polish. All car wash products and polishes should not be used on the tonneau cover, as well as, high pressure hoses and brushes.



TAUNOTENT

+27 (0)11 026 4790 / (0)11 455 0627

www.taunotent.co.za info@taunotent.co.za

Unit 3, 159 Greenvale Road, Wilbart, Germiston