



TAJNOTENT



This fitment instruction applies to a Tata Xenon Clip on tonneau kit

Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

1. Remove 2x bolts located at the front of the loadbody using the appropriate Allen key. Replace bolts, securing the provided 'L' bracket as pictured.

2. Secure the front aluminium slider rail using the 2x 'L' brackets previously installed and the 2x nuts and bolts provided.

1.



2.



2. Bolts to secure front rail



3. Secure the 2x side rails to each side of the loadbody using the provided clamps.

4. Note the positioning of the side rails so that the front of the rails are positioned as illustrated in relation to the front slider aluminium rail.

3. Positioning of clamps



4. Side rail positioning



5. Install the back aluminium rail over the tailgate by inserting the black corner pieces into the previously installed side rails. Secure by tightening the hand grip screws.

6. Insert the 2x spring steel support bars into the 4x black support brace clips located between the clamps securing the side bars.

5. Insertion of the rear rail



6. Support bars inserted





TAUNOTENT

INSTRUCTIONS FOR FITMENT CONTINUED

7. Slide the beaded part of the tonneau cover into the groove of the front aluminium rail until even lengths of the cover protrude from each side.

8. Fasten the tonneau by first fitting the socks around each roll bar and then starting to clip the cover into place using the plastic clips, beginning over the tail gate. Secure by inserting the plastic clips into the aluminium rail lip and pushing down.



8. Socks fitted around roll bar



8. Tonneau clipped into place



9. Final view of the tonneau cover fitted.

9.



Retighten clamps and hand screws regularly as they tend to open while traveling

Should you experience any problems in fitting please do not hesitate to call us on 0861 82 8668

Warranty: The stitching is guaranteed for 6 months. Please only use Sunlight dish soap to wash the cover and Dublin to polish. All car wash products and polishes should not be used on the tonneau cover, as well as, high pressure hoses and brushes.



TAUNOTENT

+27 (0)11 026 4790 / (0)11 455 0627

www.taunotent.co.za info@taunotent.co.za

Unit 3, 159 Greenvale Road, Wilbart, Germiston