



TAJNOTENT

INSTRUCTIONS FOR FITMENT



These fitment instructions apply to a
TOYOTA LWB with & without roll bar

Part No:
TH19

Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

TOOLS

Tools required: Electric drill;
10mm Drill bit; screwdriver.
Rivenut gun

Note: After any holes are drilled apply rust inhibitor (provided) before any screws or rivets are fastened.

KIT COMPRISES:

- 1x Tonneau cover
- 2x Support braces
- 4x Support clips
- 1x Triangular lace hooks
- 1x Front rail
- 2x Bobbins
- 12x Self tapping screws
- 1x jar rust inhibitor

INSTRUCTIONS FOR FITMENT

1) First attach aluminum rope section open end facing cab window and flush with edge of load box. Drill 4 holes through aluminum into load box one in each corner and in centre equally spaced. Use self tappers to secure. Now slide cover through rail.



2) Pull cover towards back and mark centers of support belts on inside of load box near top edge. Place bow clip in centre of mark and mark holes to drill, Lip of bow clip to be at top. Drill holes and use self tappers to secure.



3) Insert support bars through slots on underside and then push into bow clip.



4) Pull cover to back and mark back corners between 2 loops 4 Cm down from top edge. Drill and rivet bobbins.

5) Mark centre of tail gate then drill and rivet lacing hooks.



6) Pull cover over back corners and secure shock cord on tailgate clip securing on either side and tying off at and hook into plastic.

7) Should any part of the kit be lost or broken they can be purchased separately.



Once fitted the cover should fit tight and secure. Check that the elastic is pulled tight and that the support brace is inserted and working correctly. Only use a mild soap when cleaning your cover. Thank you for your purchase, we hope it meets your requirements adequately.

Should you experience any problems in fitting please do not hesitate to call us on 0861 82 8668

Warranty: The stitching is guaranteed for 6 months. Please only use Sunlight dish soap to wash the cover and Dubbin to polish. All car wash products and polishes should not be used on the tonneau cover, as well as, high pressure hoses and brushes.



TAUNOTENT

+27 (0)11 026 4790 / (0)11 455 0627

www.taunotent.co.za info@taunotent.co.za

Unit 3, 159 Greenvale Road, Wilbart, Germiston