



TAJNOTENT

INSTRUCTIONS FOR FITMENT



This fitment instruction applies to a Mitsubishi Triton LWB with and without roll bar

Clip on kit with and without roll bar

TOOLS:

Only tools required are a drill and 10mm drill bit, rivet nut tool (optional) and a screwdriver.

KIT COMPRISES:

- 1x Tonneau cover
- 3x Support braces
- 8x Support clips
- 1x Front rail
- 5x Rivnuts with 5x screws and washers.
- 2x Side rails, with end caps
- 1x Back rail
- 2x Plastic back corners with 4x hand screws
- 4 x G clamps and high leveling screws

1) If the black rubber around roll bar prevents fitment of rail on sides then cut off a bit accordingly using a blade

2) Place the aluminum slider rail on the cab protector the rope section part of the aluminium slide rail must be above the side rails as seen in picture, beneath the window. Make holes according to rail and drill using 10mm drill bit. Insert rivnuts into holes and use screws and washers to attach rail to edge. The aluminum stopper on the side rails must be pushed to the front of the cab protector against the aluminum rope section of the rail to secure the sides of the aluminum rope section rail.



3) Fasten the two side rails using 2x clamps per rail. The plastic caps must sit flush with the front outside edge of the cab protector. See Picture.





TAUNOTENT

INSTRUCTIONS FOR FITMENT CONTINUED

Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

- 4) Slide cover into front rail and close velcro around roll-bar and then pull cover towards tailgate.
- 5) Line up all the chips at tailgate first and then push them all down at once so that they clip into the rail. Do the same on the two sides.



- 6) Pull the corners using the tabs. When removing the cover start by lifting up the tabs to loosen the chips. The tailgate can open and close with the cover fitted.



- 7) The cover can be rolled to the front and fastened using the straps.
- 8) Should any part of the kit be lost or broken they can be purchased separately.



Retighten clamps and hand screws regularly as they tend to open while travelling. Should you experience any problems in fitting please do not hesitate to call us on 0861 82 8668

Warranty: The stitching is guaranteed for 6 months. Please only use Sunlight dish soap to wash the cover and Dubbin to polish. All car wash products and polishes should not be used on the tonneau cover, as well as, high pressure hoses and brushes.



TAUNOTENT

+27 (0)11 026 4790 / (0)11 455 0627

www.taunotent.co.za info@taunotent.co.za

Unit 3, 159 Greenvale Road, Wilbart, Germiston