

CLIP ON TONNEAU COVER FITMENT INSTRUCTIONS



TONNEAU COVER

This fitment instruction applies to:
PEUGEOT LANDTREK WITH ARTAV SPORTSBAR

Tool requirement for fitment:

Rivnuts gun, No.10 socket
Short extension & ratchet

Tonneau kit comprises:

1 x Front rail, 2 x side rails, 1 x back rail & 2 x back corners, 2 x support braces, 4 clamps & tonneau cover.

Small packet contains: rivnuts, screws and washers



1. Place rail as shown and use as a guide to pinpoint where the holes are located under the rubberising and mark with a pencil



2. Take blade to scrape away rubberising where marks are made



3. Insert rivnuts



4. Attach front rail using bolts and washers



5. Place side rails as shown on either sides



6. Tighten clamps to hold the rails firmly in place



7. Insert tailgate rail by pushing the corner pieces into the side rails and tighten screws



8. Insert square tube braces as per markers



9. View of frames and braces fitted



10. Slide cover through front rail and pull towards the back



11. Peugeot Landtrek fitted

WE THANK YOU FOR PURCHASING A TAUNOTENT PRODUCT

Warranty: The stitching is guaranteed for 6 months. Please only use Sunlight dish soap and water to wash the cover and Dubbin to polish. All car wash products and polishes should not be used on the tonneau cover, as well as high pressure hoses and brushes.



TAUNOTENT

+27 (0)11 026 4790 / (0)11 455 0627
www.taunotent.co.za info@taunotent.co.za
Unit 3, 159 Greenvale Road, Wilbart, Germiston