



TAUNOTENT

INSTRUCTIONS FOR FITMENT



These fitment instructions apply to:
ISUZU: Double Cab and Extended Cab

Standard with
and without
roll-bar

Model No.
TT40/ TT43/
TT44/
TT47/TT48

Thank you for choosing our product. Please adhere to these instructions as closely as possible. Always ensure all safety equipment is used and that a safe working environment is established.

TOOLS:

Electric Drill, 4.5mm steel drill bit, extension cord, pop-rivet gun, tape measure, pencil, all appropriate safety equipment and all parts provided in the tonneau kit.
Note: After any holes are drilled apply rust inhibitor (provided) before any screws or rivets are fastened

INSTRUCTIONS FOR FITMENT

1. Before commencing fitment, check the contents of the kit and ensure it is the correct cover for your bakkie by laying it over the load-body and ensuring it fits correctly.

2. Place the aluminium rail on the front of the load-body and secure by drilling 4 equally spaced holes into the aluminium rail and load-body. Secure using screws provided. Note the orientation of the aluminium rail.



3. Mark on the bakkie where the hooks must be fitted to secure the tonneau cover. These markings must correspond to the cut-outs of the cover, where the elastic can be pulled through. The markings must be 4cm below the top edge of the load body.



4. Drill and fit the hooks for around the trucks body using rivets. Bobbin hooks must also be fitted above the tail lights as illustrated, between 2 loops under the back corner of the cover



5. Fit the 2 bow-clips for the support brace. These clips are fitted onto the inner part of the load- body and their positioning must correspond in the centre of the sleeve stitched under the tonneau cover where the support brace slides through.



6. Lastly, saddle hooks have to be fitted, these 2 hooks ensure the elastic in the cover is pulled tight and the cover fits snug. Two holes must be drilled as far forward as possible from the front side of the load body as shown.



Once fitted the cover should fit tight and secure. Check that the elastic is pulled tight and that the support brace is inserted and working correctly. Only use a mild soap when cleaning your cover. Thank you for your purchase, we hope it meets your requirements adequately.